








Pennyfarthing Bicycle

© 2002 Brent Marshall www.eightlines.com




That's it for the pre-creasing!


As you fold the horizontal and vertical folds, the angles will fall into place. Just squash to the form shown in Step 7.



Pull the corner up slightly, but do not fold, so that you can see the folds in Step 8.





Pull the inner layer over so the folds are symmetrical on both sides.




Valley fold the top layer inwards and under the folds you created in Step 8.

Pennyfarthing Bicycle

© 2002 Brent Marshall www.eightlines.com




Flip Over





Flip Over




Sink the top layer.



Sink the top layer.



Pre-crease.



This fold will stand straight out just like a kick-stand. Tuck the top corner inside.

Flip Over

